

- 1. Junction B / SM-JC41
- 2. Junction B / SM-JC41
- 3. Junction A / SM-EW90-A
- 4. Battery / SM-BTR2

